

E-BIKE ASSEMBLY GUIDE

40 min



<p>STEP 1 Cut the tape on top edges to lift the top sides to unbox your e-bike.</p> <p>STEP 2 Additionally, carefully cut the box on the sides to use as a base for assembling.</p> <p>STEP 3 Find the tools and parts included. (may vary by model)</p> <p>i 1-2 WEEKS It is recommended, whenever possible, to keep the box for 1-2 weeks in case of return.</p> <p>STEP 1 Carefully cut the tape from the box top edges, avoid cutting the bike inside. Then open the box from the top to see the contents. You may want to cut the box on the side to use it as a base to lay your e-bike for assembly.</p>	<p>STEP 2 Unbox your brand new Cyrusher e-bike. We suggest you use one side of the box to protect the paint from scratches when assembling the bike.</p>	<p>STEP 3 Using the tools provided loose the top and side stem bolts.</p>	<p>STEP 4 Rotate the stem head 180°</p> <p>NOTE: The lower part should not rotate (make sure you loosen the top bolt before rotating the top part.)</p>
<p>STEP 5 Release the 4 front bolts of the stem cover.</p> <p>STEP 6 Separate them.</p>	<p>STEP 7 Place the handlebar inside the stem.</p> <p>Computer display facing inwards.</p> <p>Cabling facing outside.</p> <p>STEP 8 Screw bolts loosely into position to allow handlebar to be adjusted before fixing it firmly into place by tightly screwing the bolts into position.</p> <p>Fasten in an X order for a better tightening.</p>	<p>STEP 9 Insert the seat post into the frame, adjusting it according to your height and the safety line. Fasten the side nut of the seat post clamp, then lock the handle to secure the seat to the frame.</p>	<p>STEP 10 Turn the bike over so the front fork faces up and install the front wheel (make sure disc rotors from the front and rear wheels are on the same side).</p> <p>To prevent the computer display from being damaged, position it so it does not come into contact with the floor.</p>
<p>The disc rotor must fit inside the disc brake perfectly.</p> <p>STEP 11 Place nuts and washers in the order shown. The inner nut is on the side without disc brake pads. Tighten the nuts on both sides to fix.</p>	<p>STEP 12 If included, attach headlight by removing front headlight bolts and positioning headlight before loosely screwing bolts back in place. Finally, adjust the headlight to the desired position then tighten.</p>	<p>STEP 13 Choose the correct Left (L) and right (R) pedals (look for the marks), important to avoid damage the crank, then insert it into the crank aperture.</p> <p>STEP 14 Manually turn the pedal clockwise (some pressure may be needed to guide it in), then use the wrench to tighten the bolt.</p>	<p>STEP 15 Use the air pump provided to inflate the tires to the suggested pressure indicated in the sidewall of the tire. IMPORTANT: Do not overinflate or underinflate the tires.</p>

Need more information? visit www.cyrusher.com

Congratulations! You've made it! Now enjoy your new Cyrusher E-Bike!

2022/1 V2-F for Cyrusher Kommoda