

ALPENA **LINK**
EXTENSION KIT 48
 PART #: 78414

⚠ WARNING: THE FAILURE TO FOLLOW THESE INSTRUCTIONS WHEN INSTALLING THE LED STRIPS MAY CAUSE ELECTRIC PROBLEMS IN YOUR VEHICLE WHICH COULD CAUSE VEHICLE DAMAGE, ELECTRICAL SYSTEM DAMAGE, FIRE, ELECTRICAL SHOCK, PERSONAL INJURY OR DEATH.

INSTALLATION GUIDELINE

This product has a distinct amperage draw and power input rating below in the installation instructions. THIS RATING MUST BE FOLLOWED. If you are not confident in your ability to install the AlpenaLINK™ Extension Kit 48 (the "product"), please consult a licensed mechanic.

The product must be installed in a properly functioning vehicle electrical system. Do not install this product in a malfunctioning vehicle electrical system. Do not modify the product in a way that is not intended in the instructions below.

The intended use of this product is to provide extended wiring for accent & auxiliary lighting for off road use only. This product is not DOT approved.

⚠ WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov.

⚠ WARNING



BE SURE TO USE SAFETY GLASSES AT ALL TIMES WHEN INSTALLING THIS PRODUCT.

If removing interior panels, start here:

- 1** DETERMINE THE EDGE OF THE PANEL AND THE SIZE OF THE GAP, AND IF THERE ARE ANY FASTENERS PREVENTING THE PANEL FROM LIFTING AWAY
- 2** INSERT THE APPROPRIATE END OF THE TRIM TOOL, GENTLY WEDGING INTO THE GAP BETWEEN INTERIOR PANELS

INSTALLATION INSTRUCTIONS

- 3** WHEN THE THIN PORTION OF THE TOOL IS FULLY INSERTED INTO THE GAP, GENTLY PRY BACK ON THE TOOL TO LIFT THE INTENDED PANEL AWAY FROM THE INTERIOR, GOING SLOWLY AND USING ONLY AS MUCH FORCE AS REQUIRED
- 4** SLOWLY AND GENTLY WORK THE TOOL ALONG THE GAP, POPPING THE PANEL LOOSE
- 5** WHEN THE ENTIRE SIDE OR PORTION OF THE PANEL HAS LIFTED, CHECK TO SEE IF THERE ARE ANY FASTENERS OR CLIPS HOLDING THE PANEL DOWN THAT WERE PREVIOUSLY OUT OF SIGHT
- 6** IF THERE ARE FASTENERS, TAKE THE APPROPRIATE STEP TO REMOVE THEM
- 7** SLOWLY AND GENTLY PULL THE PANEL AWAY
- 8** ROUTE THE LED EXTENSION CABLE OR PLACE THE LED STRIP IN A PLACE OR POSITION THAT WILL NOT OBSTRUCT THE REPLACEMENT OF THE REMOVED PANEL, WILL NOT DAMAGE THE WIRING OF THE EXTENSION OR THE LED STRIP
- 9** REPLACE ANY HIDDEN FASTENERS REMOVED IN STEP NUMBER 6
- 10** SLOWLY AND GENTLY REPLACE THE INTERIOR PANEL



⚠ WARNING

DO NOT CONNECT A COMBINATION OF STRIPS THAT EXCEED 3 AMPS TOTAL POWER DRAW

Wiring LED Strips Using the Extensions

- 1** MEASURE AND OR TEST FIT LENGTHS OF EXTENSION AND LED STRIP TO ENSURE ALL WIRING AND STRIP PLACEMENT IS WHERE YOU WANT IT TO BE AND DOES NOT OBSCURE ANY VEHICLE FUNCTIONS OR DAMAGE ANY INTERIOR PANELS OR COMPONENTS
- 2** INSTALL THE LED STRIPS AS PER INSTRUCTIONS INCLUDED WITH THE STRIPS, DO NOT CONNECT POWER
- 3** LINK THE ALPENALINK™ EXTENSIONS TOGETHER
- 4** CHECK ALL CONNECTIONS BEFORE CONNECTING POWER
- 5** TUCK ANY EXCESS WIRING SAFELY AWAY AND SECURE FROM ANY HAZARDS SUCH AS SEAT RAILS, PEDALS, VENTS

⚠ WARNING:
 DO NOT LINK MULTIGLOZ™ STRIPS AND MAX / FLEXLED™ TOGETHER
 DO NOT USE THE MULTIGLOZ™ INPUT CHANNELS FOR MAX / FLEXLED™ STRIPS
 DO NOT USE THE MAX / FLEXLED™ INPUT CHANNELS FOR MULTIGLOZ™ STRIPS

WARRANTY

The manufacturer warrants the AlpenaLINK™ products when they are properly installed, connected, and operated, for a period of 1 year from the date of purchase. The warranty is void and neither the manufacturer nor the retailer is responsible for any product failure, damage, or injury if these instructions are not strictly followed.

Patent: USD836.071S / US1044383B1

Marklyn Group Inc.
 753011 2nd line EHS Mono,
 ON, Canada L9W 5W4

Alpena® is a registered trademark of Marklyn Group Inc.
 © Copyright 2022

Made in China

NORTH AMERICAN SUPPORT AVAILABLE



@AlpenaAutomotive
 1-800-387-3217