


Assembly steps

1. Screw 2 upright frames together at the bottom with connectors, use the assembly aid at the top as a distance!
2. place the upright frame in front of the wall and secure with level
3. mark drill holes (2 x per frame) on the wall.
4. drill and dowel wall properly.
5. fix the upright frame with screws and spacers to the wall
6. repeat step 1 - 5 depending on wall elements.
7. check screw connections
8. fix shelf bracket on right and left side with 2 screws each to the wooden shelf board. (use only the 2 outer holes)
9. hook in display rack

If diagonal connectors are used, steps 3-5 are not necessary.

Attention!

When using presentation boxes and heavy goods, it is absolutely necessary to fasten the frame to the wall. Proper fastening must be ensured.

 MANDAI DESIGN <small>HOME OF SHOP IDEAS</small> www.mandai-design.de	Projekt	Datum:	
	System Addison		Maßstab: 1:20@A4
Adresse: Straße der Deutschen Einheit 4b • 04643 Geithain • Germany	Planbezeichnung:	Zeichnungsnr.: 1/1	
Fon: ++49(0)34341 - 40709-50	Mail: info@mandai-design.de	Assembly steps	
		Gez.: ks	Gepr.: dh