



## Canvas Frame System Installation Instructions

### Tools you will need:

13mm Socket, Socket Wrench, 8mm Allen Wrench, 6mm Allen Wrench

1. After unwrapping, put the two-piece frame together with bolts provided. (3/8 shorter/fatter bolt)



2. Open the Slingshot hood.





3. Remove the mirrors, and mirror brackets.



4. Starting from the rear, place the frame on the Slingshot. The two back plates go on the back headrest on the front of the roll hoop. Attach and tighten halfway with four shorter/skinnier bolts (35mm). The four long bolts (12mm) go into where the mirror brackets were. Tighten halfway on each side. Once all bolts are in place, tighten the remaining bolts. Put mirrors back on with same OEM bolts.





**CARE:**

- Use a non-abrasive cleaner for heavy dirt.
- A microfiber towel has been included for light dust.

