

OMNIPURE EFS4 INSTALLATION INSTRUCTIONS

3/8" FPT Inlet Valve With Shutoff

3/8" FPT Outlet Tee



1. Connect water inlet line to the 3/8" FPT water inlet valve.
2. Connect the supplied 3/8" tubing to the Bleeder Valve by pushing the tubing into the valve until it stops.
3. Connect the water line from the espresso machine to the 3/8" FPT water outlet valve.
4. Turn bleeder valve downward and turn water supply on, let 3-5 gallons of water pass through the system to purge the cartridges.
5. Shut water supply off and turn the Bleeder Valve off which allows the water to pass through to the espresso machine.
6. Turn water valve back on and purge your espresso machine of air.