

DO IT YOURSELF LINING

There is available a 3-piece, lightweight plastic stencil, complete with all the lines, numbers and 10 off. Use the stencil kit along with a can of white spray paint and line your patio, driveway or existing shuffleboard court fast and efficiently.

The shuffleboard diagram stencil kit contains three (3) pieces of plastic. First open the box and allow the stencils to flatten. Second, use wood or other weight to hold each stencil down so you get a good line.

Place stencil A on the left side of the court. Spray on the lines. Next, place stencil B on the right side of the court. Spray lines. Stencil C is also used to put the dead lines on the court.

