

**Ranch Skirt Guide** 

## A Standard Kit Includes

- 42 x Fascia Board 2400mm x 25mm x 150mm
- 4 x Routed Corner Post 610mm x 53mm x 67mm
- 10 x Routed Through Post 610mm x 53mm x 67mm
  - 28 x Post "L" Bracket
  - 14 x 610mm Picket

## Screws and tools are not included

The routed ranch posts should be first cut to the required height, make sure that the majority if required is cut from the bottom of the post so that you will always start with a full fascia board directly beneath the home. On uneven ground the 3<sup>rd</sup> or lowest fascia board to the ground is the one that will need to be scribed (cut down) along its length to suit the required height.

We recommend starting with a corner post first. Using a suitable level to mark on the base/ground where the "L" bracket can be attached directly beneath the home, measure and cut the post to the required height (measure twice to be sure!!) Depending on how the bottom of your home is finished you may find it easier to cut the inside top of the post to a slight angle, this will make it easier to attach to the home with a suitable screw from behind. Make sure the screw is not too long as it may protrude through the front wall of the home and damage the outer skin. Once your "L" bracket is attached to the ground the post can be positioned over it and

secured to the inside bottom of your home, the posts should not protrude the outer skin of the home. See Images below.



We the suggest temporarily fitting the opposite corner post in the same way and then stringing a line between the 2 to keep all the mid posts inline which should be fixed at equally spaced intervals between the corner posts at a maximum of 2410mm centre to centre of post. You can then work your way around the home adding the posts and fascia boards which are slotted into the prerouted ranch posts



After you have added the 3 fascia boards between 2 posts you will need to attach a length of picket with screws in the centre between the posts from behind to keep everything inline. image below.



You can also add a screw through the back of the ranch post to hold the fascia in place to the post if required as added security.

On some home where the chassis rails run to the outside of the home the Fascia Boards may need to be notched in the back skin with a multi tool to allow them to sit further back if you would like the boards to finish flush with the outer skin of your home.

