

**DH LABS**

9638 NW 153rd Terrace
Alachua, Florida 32615
Phone (386) 418-0560
FAX (386) 462-3162
www.silversonic.com

Termination instructions for Silver Sonic BL-1 Interconnect cable. DHLABS-57225

RCA Plugs

Source end:

1. The red lead connects to the center pin of the RCA plug.
2. The black lead and the drain wire connect to ground on the RCA plug.

Load end:

1. The red lead connects to the center pin of the RCA plug.
2. The black lead connects to ground on the RCA plug.
3. Cut the drain wire (do not connect it) and insulate it if necessary.

XLR Connectors

1. Connect the drain wire to pin 1 of the XLR connector.
2. Connect the red lead to pin 2 of the XLR connector.
3. Connect the black lead to pin 3 of the XLR connector.

We recommend using a good quality silver solder. The SN-62 alloy (62% tin, 36% lead, 2% silver) is very easy to use and works very well. Manufactured by Kester and others. (Available from Radio Shack as part #64-013.) For RoHS compliant applications, the Cardas Tri-Eutectic solder is a good choice.

Suggested tools

Ideal Industries #45-120 wire stripper.
Ideal Industries #45-165 outer jacket stripper
Ungar/Xcelite 170M flush cutter.