

A-dec Style 3 Hole Foot Control Installation

(Model #04-40- no accessories)

Step 1- Turn the unit off.

Step 2- Note where each line of your existing foot control is connected and disconnect.

Step 3- The large “ribbed” tubing connects to the source of air in the junction box. The large “non-ribbed” tubing connects to the unit for drive air. The small tubing is air into the unit and should be connected as the original foot control was.

Step 4- Apply liquid soap to tubings and slip sleeve clamps over tubings (approx. 3/8” from end) with the internal bevel facing the barb.

Step 5- Slip the tubing over the barb and lock tubing by sliding sleeve clamp over tubing portion on the barb with pliers or sleeve tool.

Step 6- Turn unit on and test for leaks and proper function.

Note: Take care not to break barbs when installing tubings and clamps. Inserting tubing ends in hot water will further aid this process. If the foot control “hisses” before activation, the large tubings are hooked up in reverse.

