

How to Install

MURAL DOT APPLICATION GUIDE

Wait! Before you begin...

Our Mural Dots may be the easiest Decal application you've ever experienced!

In fact, by following only 4 steps, you'll have a stunning looking wall.

Before you begin, it's important to remember that our decals work best with matte, eggshell, satin or semi-gloss paint finish and are not recommended on highly textured concrete, highly textured wallpaper, stucco, or primer finishes. Now, let's get started shall we?

STEP 1

Give your wall a quick wipe down with a damp cloth to create a clean, smooth, dust free and dry surface.

Note: Allow 2 weeks for paint to cure before applying your Decal.

STEP 2

Tape the design to the surface with masking tape to make sure it's exactly where you want it. Use a level if necessary.

STEP 3

Fold back the top of the design, begin peeling the white backing paper from the graphic at a 45° angle about 20cm from the top. Then rub the exposed section of the dot onto the wall.

STEP 4

Continue to rub the remainder of the design onto the wall while peeling off the white backing.

If your decal is large, ask a friend for help. Otherwise you should be able to manage the application in one step.

REUSABILITY

Our Mural Dots are made from a Woven Fabric with thin canvas finish in matte. They are removable, repositionable and reusable. That means, if you put it on wrong, simply peel it back off and do it again! Keep the backing paper if you wish to move your decal to new location in the future.

STYLE YOUR SPACE!

With the coolest backdrop in town, add those funky fresh details to really make your space pop. Colour matching the decal with a cushion or art print will create a cohesive flow and wow factor in your space. Hashtag #yourdecalshop with a photo of your decal installed to go into the draw to win free gifts!

YOUR DECAL SHOP

www.yourdecalshop.co.nz | info@yourdecalshop.co.nz