



This solder jumper is a "net tie".
It should be the only place AGND touches GND.

Fluxamasynt 3
<http://moderndevic.com/Flux3>
 by Nadya B.
 FluxR3-v7
 12/3/15 2:08 PM
 Sheet: 1/1