


# MAZDA MOTORSPORTS

# By: PENSILE RACING SHOCKS.

# **MX-5 SPEC MIATA FRONT SHOCK**



**LOWER NUT** 

1 ¼" (32mm) Torque 50ft-lbs (68 N-m) Apply 243 Loctite to threads

#### **OEM MOUNTING PLATE- NC10-28-340C**

Not included in kit – follow mount modification instructions below prior to reassembly

# **BELLEVILLE WASHERS (3 QTY)**

**UPPER NUT** 

To be stacked with base of cone oriented against the upper mount. See cross section view for example.

### SHIM SPACER


Provides hard durable surface for Belleville washers.


# 10mm ID MONOBALL

Eliminates side load on shaft as opposed to fixed stud mounting styles.

### **MOUNTING NUT SPACER**

Install on end of shaft before threading Nyloc jam nut (damper is delivered with this nut threaded on end of shaft)





# **TOP MOUNT MODIFICATION:**

- 1. Remove mount from vehicle
- 2. Secure mount to table of drill press/mill
- 3. Using high speed step drill bit & cutting fluid, enlarge existing thru hole to Ø.938 (15/16"). (Step drill can be purchased from any industrial supplier such as McMaster-Carr, MSC, Grainger, etc.)
- 4. Chamfer/deburr hole edges
- 5. Assemble mounting components as specified above
- 6. Re-install into vehicle



RACING SHOCKS

150 FRANKLIN ST • P.O. BOX 1056 READING, PA 19602

(610) 375-6180 • (610) 375-6190 FAX