



45 Powers Road, Westford, MA 01886

### UNIVERSAL STAINLESS STEEL EMBLEM INSTALLATION INSTRUCTIONS

- Stainless steel logo graphics and insert letters are designed to enhance your vehicle with a chrome like representation of the make or model name or logo representation.
- They are waterproof and will not rust on the hull of your boat, bumper of your car or any application purpose that suits your needs.

#### \*\*\*INSTALLATION INSTRUCTIONS\*\*\*

The toughest part is aligning it correctly.

#### step 1.)

- ☒ Clean work area, free of airborne dust
- ☒ Vehicle and Trim temp above 65F
- ☒ 3M Adhesive Cleaner (PN 08984) or equivalent
- ☒ Soft Clean Cloths
- ☒ Utility Knife
- ☒ Masking Tape (optional)
- ☒ 3M Adhesive Promoter or equivalent (recommended)

#### step 2.)

1. DO NOT REMOVE RED TAPE LINER OR PROTECTIVE COVERING until instructed to do so
2. TEST FIT EVERY PIECE. Check that the shape and roll of each piece properly conforms to the contour of the vehicle. Note the proper placement and alignment for your kit (see fig 1 & alignment tip)
3. CLEAN RECEIVING SURFACE JUST PRIOR TO INSTALLATION. Use 3M adhesive cleaner (or equivalent) to clean area thoroughly and allow to completely dry
4. APPLY 3M AHESIVE PROMOTER. If installing on plastic an adhesive promoter (preferably 3M) should be applied before installation

#### step 3.)

1. FOR SMALLER PIECES, remove the entire red liner just before installing. Protect exposed tape from contaminants.
2. HOLD THE PIECE AT A 90 DEGREE ANGLE TO THE VEHICLE and touch the very top edge of the vehicle, observing your placement and alignment guides. If you need to adjust placement, simply raise the piece past 90deg and lift off.
3. ONCE YOU GET THE PLACEMENT RIGHT press down across the top of the piece to tack it in place.  
FOR SMALLER PIECES complete installation by pressing down across the piece, moving top to bottom to complete installation.
4. APPLY PRESSURE OVER ENTIRE SURFACE INCLUDING EDGES with a soft clean cloth to ensure that the tape completely adheres to the vehicle. Check your edges and re-apply pressure when necessary.
5. LASTLEY REMOVE PROTECTIVE COVERING. You may use any non-abrasive stainless steel cleaner to keep your trim shining bright!  
(EVEN A DRY PAPER TOWEL WILL DO)