



GUTTERS

STEP-BY-STEP PROJECT WALK THROUGH

1

PREP YOUR SPACE AND GATHER YOUR MATERIALS

Make sure all surfaces are clean, dry, and free of all matter.

2

DETAIL WORK

Remove backing on Liquid Rubber Seam Tape and bridge joints/seams with tape. Lay Liquid Rubber Seam Tape loose and flat, do not stretch. Apply pressure to adhere Seam Tape.

3

MASKING

Apply painter's tape while to protect surfaces you do not want to coat.

4

APPLY COATING

Apply a thick coating of Waterproof Sealant. Apply the next heavy coat when the product is dry to the touch, and nothing is wet underneath. Tacky is ok.

5

CLEAN UP

Pull up painter's tape while coating is still wet. Close container to secure leftover product. If spillage occurs, soak up as much material as possible with rags. Clean immediately with soap and water. If spill is dried, scrape off as much as possible with a razor or scraper. Use mineral spirits to weaken product and an appropriate tool such as a wire brush or grinder to mechanically remove. If splashed on the skin immediately wash thoroughly with fresh water. If the product has dried on the skin massage the area with medical grade mineral oil, baby oil or edible oil, then wash with soap and water. If irritation persists, seek medical attention.



TIPS FROM THE PROS

- Avoid hot, direct, intense sunlight during application.
- Do not apply if dew or rain is forecast.