

## IM METER TO BOP GUN ASSEMBLY

1. Prior to assembling adaptor (4) to the gun (2), remove nozzle (3) from the gun (2).
2. Thread shorter end of adaptor (4) to the gun outlet (2) - Do not over tighten.
3. Insert locknut (5) into the longer end of adaptor (4).
4. Thread meter (1) inlet into the long end of adaptor (4). Align the meter (1) and tighten the locknut (5) to position the meter (1) at required angle. Shorter thread length into (2) gun outlet
5. Insert stop sleeve (6) into the outlet end of meter (1).
6. Thread nozzle (3) to the meter outlet (1) - Do not over tighten.



Item No	Qty	Part of Kit	Description
1	1	N/A	ELECTRONIC OIL METER
2	1	N/A	BOP TRANSFER GUN
3	1	N/A	BOP TRANSFER GUN
4	1	BP-MAK	1/2" ADAPTER
5	1		1/2" LOCK NUT
6	1		STOP SLEEVE