



HOW TO ASSEMBLE A PURA™ HIVE BODY

What you'll need:

- **Hivebond™ 4000 glue or other waterproof wood glue**
- **Rubber mallet**
- Optional* {
 - Staples or nails
 - Hammer or pneumatic stapler/nailer
 - 2x4 board to soften the mallet blow

STEP 1

Place a dot of wood glue in the mortise of each dovetail. Brush to cover the mortises for max strength.



STEP 2

Join the box sides with a rubber mallet (soften the blow with a 2x4 if desired). The box is self squaring.
(Hint: Be sure to examine the handles for proper orientation.)



STEP 3 (OPTIONAL)

Staple or nail the box corners from the front (i.e., shorter end) board. For deep-sized boxes, place an additional staple or nail in between the corners.

