



**GRASSROOTS
REFEREES**

www.grassrootsreferees.com

County F.A. Shirt Badge Self-Iron Instructions

1. Set iron temperature to 2 dots (150°C)
2. Place shirt on flat hard surface (table or worktop)
3. Place badge on left breast pocket and smooth out shirt
4. Cover badge with towel or cloth garment, making sure badge does not move
5. Press iron down hard on badge for 20-30 seconds and gently move iron around in circular motion
6. Leave to cool for 2-3 minutes
7. Peel off cover film from corner smoothly and at a sharp angle
8. Place film that has been removed over badge and repeat steps 1-5
9. Leave shirt/badge to cool down before folding

www.grassrootsreferees.com

For further information on our refereeing products contact

sales@grassrootsreferees.com