A B N O R M A L S A N O N Y M O U S

HANGING INSTRUCTIONS PRINTED GRASSCLOTH

Grasscloth is a handmade product. It is woven with natural fibers that give the finished product a certain unevenness. Being handmade and hand stained, it is common that shades will vary from roll to roll and from end to end of a single roll. For these reasons we urge you to take extra care in examining the rolls before you hang, and during the actual installation.

PLEASE READ THROUGH BEFORE HANGING. Inspect all goods before trimming or pasting. No claims will be made on any wallcovering that has been trimmed or pasted. If you have any defects, please stop and contact your supplier before proceeding

NOTE: The highest quality of workmanship is employed in the production of the wallcovering. Careful inspection is made before shipment. However, final inspection and approval are the ultimate responsibilities of the customer. Correct design, color, and quantity should be verified before the wallcovering is cut or hung.

WARNING:

Do not get adhesive or water on the wallcovering surface. Any paste or water on grasscloth material will discolor and cause staining to the product.

Prior to placing your order, we recommend that wallcovering quantities for your project be carefully calculated as there are NO returns allowed for custom digitally printed items. Our wallcovering is delivered untrimmed and requires pasting. Upon receiving your custom wallcovering and prior to installation, please examine all goods to make certain the size, image and quality are satisfactory and as ordered. Check to see that you have received the artwork and quantity ordered and that all panels are included in the shipment. If the material is to be stored, make sure the pieces are stored flat in a temperature controlled, dry area, and not crushed.

Strips must be table trimmed. Material is not pre-trimmed.

Special care should be taken to avoid any paste from getting on the face of the material.

If any paste gets on the material, immediately remove with a soft rag and dry moisture with a towel.

PREP:

Proper wall preparation is essential. Our wallcovering can be applied to almost any properly prepared wall surface in sound condition. Walls must be smooth, clean, dry, and free of mildew grease and stains. Apply a stain killing primer if needed. Old wallcovering and calcimine must be removed and enamel surface should be dulled by sanding and sealed. All surfaces must be properly prepared using a professional latex based primer, such as Roman Adhesive, R-35 Oil Base Products should be avoided. Adhesive & wallcovering must be room temperature for at least 24 hours (not less than 55) prior to and during the installation

INSTALLATION:

- All rolls should be numbered. Material must be cut and installed in numbered sequence, lowest to highest.
- Inspect installation after applying no more than three (3) strips. Obtain approval before proceeding. The Manufacturer / Vendor are not responsible for claims beyond the initial (3) strips.
- Use strips in exact order as they are cut from the roll. Fill in over the door and windows as you come to them with strips cut in consecutive order from the roll.
- Paste: Use a heavy-duty, premixed clear adhesive. Paste one piece at a time, soak the strips 5 to 8 minutes then proceed with trimming and installation. After 3 panels, examine and inspect material and installation. If at any time, during the installation a discrepancy occurs, STOP, contact the designer or manufacturer before proceeding.
- Tools: Use a soft brush or smoothing blade of flexible plastic designed for fabrics for smoothing and removing air pockets
- Do not use a pasting machine when hanging this product.

If you or your installer have any further questions please contact your supplier To find a professional installer in your area, we recommend the National Guild of Professional Paperhangers at thepaperhangers.com or ngpp.org.

^{**} This wallpaper is provided on a continuous bolt **
For best results, please CUT AND HANG PANELS IN THE ORDER THAT THEY COME OFF THE BOLT.
This provides the most consistent color from panel to panel. Work in one direction around the room, with the first and last panels from the bolt meeting in a corner, doorway, etc. - rather than on a flat wall.