

****Universal Rear View Camera Installation Guide****

For specific cable routing and trim removal, please do your own research, as we cannot offer advice on specific models.

1. ****Mounting the Camera:****
 - Drill a hole in the number plate light trim to mount the camera securely.
2. ****Connect Ground Wire:****
 - Connect the black wire from the camera loom to the ground on your reverse light.
3. ****Connect Power Wires:****
 - Connect the two red wires from the camera loom to the live wire of the reverse light.
4. ****Route Video Wire:****
 - Route the yellow video wire (yellow connector) from the boot to the module or decoder location.
5. ****Connect Video Wire to Module:****
 - Plug in the yellow video connector to the decoder or module loom and the red cable to the reverse wire on the decoder or module.
6. ****Connect Camera Loom:****
 - Connect the yellow and red connectors from the camera to the corresponding connectors on the camera's loom.
7. ****Configure Decoder or Module:****
 - Set the decoder or module to recognize an aftermarket camera instead of the OEM camera.
8. ****Test the Camera:****
 - Test the camera by selecting reverse to ensure proper functionality.
9. ****Reinstall Car Trims:****
 - Reinstall any removed car trims as required for a clean and finished installation.

Note: Ensure all connections are secure and follow standard safety practices during the installation process.

