

Mason Jar Transferring Instructions

Read these instructions completely before you begin.

Supplies Needed

- Coated Mason Jar
- UltraWrap 11-15oz Adjustable Mug Wrap
- Heat Tape
- Photoshop or Corel Draw
- Design Template
- Heat Gloves

Important: Read instructions before use.

UltraWraps have been tested and proven to work successfully for hundreds of consecutive uses per wrap. However, deliberately stretching the wrap beyond its specifications can result in loss of tension or tearing. Likewise, over-heating the wrap or placing it too close to the oven heating coils can weaken the wrap, causing it to burn or tear. To ensure the full life of each UltraWrap:

- *Never* over-stretch the wrap beyond the simple distance needed to connect the hook to the support bar.
- *Never* use a wrap for a product *other than* the one it is intended.
- Do not bake the UltraWrap at a temperature hotter, or a time longer, than recommended. See Step 1 for time and temperature recommendations.
- Never place the UltraWrap closer than 3" from the oven heating coils.

Failure to follow these instructions could cause product failure and void any product warranty.

Step 1: Adjust Your Oven

UltraWraps are designed for use in regular or convection ovens or industrial conveyor ovens, *only*. Do not use in a microwave oven under any circumstances. **Preheat** oven to **Bake** at **425° F (400° F** in convection oven). For best results, oven must be at full temperature prior to using UltraWraps.

Oven Temperature: **425° F (400° F in convection oven)**
 Dwell Time: **4 ½ - 5 minutes**

Note: *These instructions, including transfer times and temperatures, are based on the inks, paper, ovens and products we use. Your inks, papers, etc. may require adjustments in your time/temp settings*

Step 2: Print your transfer(s) using this method:

- A. Open template in Photoshop or Corel.
- B. Open image file.
- C. Select the area of your image that you want to have on your mason jar. Paste into your template.

Step 3: Tape transfer to mason jar. We suggest placing a 1-inch piece on each end of the transfer near the handle.

Step 4: With the mouth of the jar pointing to the left, press the left side of the wrap (straight metal rod) against the jar.

Step 5: With your other hand, pull the handlebar up and around the right side of the jar.

Step 6: Push the handlebar all the way down past the straight bar until it locks into place on the left side of the jar.

Step 7: Place the wrapped jar on its side in a preheated oven. Do not place closer than three inches from the heating coils. **Do not use in a microwave oven!**

Step 8: Bake jars at **425° F (400° F** in convection oven) for **4 ½ - 5 minutes**.

Step 9: When done, immediately remove wrap and jar from oven. Remove wrap and transfer from jar. Items are hot! We recommend using oven mitts or heat gloves.

Troubleshooting & Tips:

- The handlebar should slide over the straight bar without struggle. If the straight bar or the handlebar show signs of bending, STOP! The wrap will only work properly when the operator stretches the wrap around the jar.
- Do not use a fan to cool off mason jars, this can cause cracks in the glass due to thermal shock.

Customer Support

For support on these or any of our products, please call our toll-free number for assistance: **877.795.1500**. You may also write to us at Support@LaserReproductions.com.