

## Vintage Signs Transferring Instructions

### Supplies needed:

- Vintage Sign (5"x20", 8"x14", or 12"x18")
- Heat tape
- Thermal Rubber Mat



### Transferring Information:

- Heat press setting: **400** deg F
- Dwell Time: **2 - 3 Min**
- Pressure: **Firm**

### Procedure:

1. Tape transfer to the coated side of the sign. (fig. 1)
2. Place sign on heat press with transfer side on top. (fig 2)
3. Cover with thermal rubber mat. (fig 3)
4. Close press with **Firm pressure** for **2-3 min**
5. Remove rubber mat and transfer, let cool. (fig 4)



**Fig. 1**



**Fig. 2**



**Fig. 3**



**Fig. 4**

**Tech Support: 1-877-795-1500**