

INSTALLATION INSTRUCTIONS

TOOL LIST

Flat-head Screwdriver

First, remove original fender liner clips on the left and right sides of the engine bay. Save the original clips to used for the final installation.

Next, invert the Airblade like the image in step 1. Then ensure the notch is aligned with the hood damper strut. Proceed by slowly rotating the Airblade forward. Keep an eye on the Airblade's position as the large angled wing must sit above the hood hinge mount and the other wings must tuck under the fender quarter-panel.



Once seated properly, re-install original fender liner clips. You're now all set!

For further installation tips, watch our installation video by scanning the Q.R. Code below.

INSTALL VIDEO >

