

INSTALLATION INSTRUCTIONS

PART LIST

- Bracket *1
- Puller Cover main unit *1
- M6 Dress-up bolt *2

TOOL LIST

- small Flat Head Screwdriver
- M6 Hex Screwdriver
- M6 Wrench

APPLICATION NOTE

Check the laser mark on the bracket to make sure it is for your vehicle.

Type D - for 2015+ WRX

Type F - for 2014+ Forester XT / 2014-19 Outback 2.5 / 2014-19 Legacy 2.5

Type N - for 2011-16 Impreza / 2013-17 Crosstrek

1. Remove OEM engine cover

Use a flat head to help taking off the fastener, and remove engine cover.


2. Remove the Bracket of the OEM engine cover

Use a M6 wrench to remove the two M6 nuts marked as below. Keep it close since we will use these again.

Reference for "D" "F"



Reference for "N"



3. Install the bracket included using the 2 stock M6 nuts.

Reference for "D" "F"



Reference for "N"



4. Install the pulley cover main unit to complete.



Use the included M6 dress-up bolts to complete the installation.