

## INSTALLATION INSTRUCTIONS

### PARTS LIST

- HEIGHT ADAPTER \*1
- SHIFT KNOB \*1

### TOOL LIST

- 6MM ALLEN KEY
- 12MM WRENCH

### APPLICATION NOTE

Good for most SUBARU manuals with M12x1.25mm thread pattern.  
This product is also compatible with our CVT sport shifter kit.

### 1. Install the height adapter

Install the adapter, and use the allen key to lock it in place before putting on the shift knob. The HEX SOCKET SET SCREW on top is for securing the adapter in place so it doesn't turn with the shiftknob whenever you need to take it off.



## 2. Install the shift knob and check the orientation of the logo.

The logo on the bottom of the shift knob might not be centered after install, and in case of that, making adjustment on the height of the height adapter will be necessary for make the logo centered.



## 3. Losen the HEX SOCKET SET SCREW to adjust hieght adapter.

Take off the shift knob, and losen the height adapter. Adjust the orientation of the adapter based on the angle you need to change to center the logo. This process might takes several times.



### \*Reminder

After changing the orientation of the set screw, remembe to tighten the set crew again before putting the shift knob back.

### \*\*Reminder

The height adapter isn't just for changing the orientation of the shift knob, it can also be used to change the height of where the shift knob finally sit. Take the time to make it sit at the most preferable height for your driving.

#### 4. Install the shift knob and ENJOY.

Once the adjustment is complete, install the shift knob again and enjoy.

