

# SMART FLOW SHROUD

## INSTALLATION INSTRUCTIONS

### TOOL LIST

Drive Ratchet | Drive Extension | Drive 10mm Socket | Drive 12mm Socket | Drive 14mm Socket | 10mm Combination Wrench  
12mm Combination Wrench | Phillips Screwdriver #2 | Flathead Screwdriver | Clip Popper | 5mm Allen Key

1. Remove 2 clips on the intake duct.
2. Remove intake duct.
3. Remove 6 clips holding the stock intake shroud.
4. Remove the bolts holding the headlights in. (x4) 2 on each side.
5. Remove the bumper side bracket bolts. (x4) 2 on each side (10mm socket)
6. Remove the 5 bolts holding the upper bumper reinforcement bar. (10mm socket)
7. Remove the upper radiator bracket. (x2) (12mm socket)
8. Remove the left bolt holding the hood latch. (12mm socket)
9. Use the supplied bolt with the 5mm Allen to fasten the Ram Air Tray on the left to the upper radiator support. Then use the hood latch from the left, to bolt the right side of the Ram Air Tray.
10. Align the main Smart Flow Shroud with the original clip holes and install the Upper Radiator brackets. Then align the upper reinforcement bar with the original holes.
11. Slide the flange under the bumper reinforcement bar bracket to the right of the hood latch. Do this before bolting the bumper reinforcement bar.
12. Once the Smart Flow Shroud is installed make sure to tighten all bolts to 15 ft/lbs of torque. Then use the steps in reverse to install the stock parts and bumper back on.

