

WALLPAPER INSTALLATION & CARE GUIDE

YOU WILL NEED:

- Scissors or Utility Knife
- Tape Measure or Ruler
- Pencil
- Spirit Level (or other leveling device)
- Drop Sheet
- Water Spray Bottle
- Clean Cloth
- Adult Supervision Recommended

1. PREPARE



Before you begin, make sure you turn off all power points for safety, remove power outlet and light switch covers before commencing the below cleaning and installation process.

Before installing our wallpaper, ensure that your walls are sealed and smooth. Clean the wall surface. Priming is always recommended for best results, especially with old, damaged or flaking paint and on a wall with uneven surfaces. This wallpaper is suitable for indoor use only.

Be sure to inspect your roll/s to ensure that they are in good condition, with no variations in colouring, and that no other faults are present. We cannot accept liability for defects that are apparent at the time of hanging, nor can we be responsible for any consequential loss.

2. LEVEL



Let's begin!

Start off by laying down your drop sheet to protect your floor and wallpaper. Roll out a portion of your wallpaper. With the help of an adult, cut off the info tag at the beginning of your roll.

Mark out the height of your wall; with 2" (5cm) added for overhang. Cut the wallpaper to make your first panel. Ensure your pattern is properly lined up before cutting the lengths of your next panels. The height of the pattern repeat will determine how much extra wallpaper you will need. Check your wallpaper tag to determine the pattern height. Make sure to always add an extra 2" (5cm) extra on the top and bottom of your panel for overhang.

If you are unsure, you can check out our [Wallpaper Installation Tutorial Video](#) for visual aid.

Take your spirit level and line it vertically against your wall where you want your first panel to sit. Place a mark down your wall every 11-15" (30-40cm). This will be your guide to ensure your first panel is vertically level.

3. SPRAY



Fill your spray bottle with tap water. A standard spray bottle can be used.

Take your first panel of wallpaper and lay face down on the drop sheet. Spray the back of the paper with water starting from one end and working your way to the other. Check that the surface of the wallpaper is visibly saturated with water. If not, apply more water using the spray bottle. We recommend water to be applied at a rate of 4oz (100ml) per 11ft² (1m²).

4. INSTALL



Line the wallpaper up against your marked line, leaving approximately 2" (5cm) of overhang. This will account for any walls that aren't square or horizontally level. It is very important to align your first panel this way to ensure your design lines up along the top of your wall. This will be trimmed later.

Align the top and bottom of the first panel before smoothing out. The material can easily be re-positioned and re-aligned during the first 10 minutes of installation. If the material is not moving easily, simply lift up the material and apply more water. Using your hand, work from the ceiling to the floor to smooth the length onto the wall. Making sure to remove any bubbles or wrinkles as you go. If needed, add more water to any areas that haven't stuck.

Repeat steps 3-4 with your next panel of wallpaper. Butt join the lengths together with the previously installed panel, matching up the edges. Ensure that the panel is properly positioned, the pattern is matching and there are no visible gaps between the joins.

Continue these steps until your wall is complete! Use a clean cloth to clean any excess paste. With the help of an adult, trim the top, bottom and sides for a perfect finish. Ensure your blade is sharp as a dull blade can tear the wallpaper easily.

...Oh, and remember to have fun!

Easy To Clean

To clean, gently wipe away any marks as quickly as possible with a clean damp cloth. Do not use any chemicals. Dry off immediately with a new dry cloth. Do not scrub. Some stains may not be able to be removed.

Removal

When it's time to remove the wallpaper (or replace with a cool new design), the product can be easily taken off in one piece. Use your water spray bottle and thoroughly wet the wallpaper, starting from the top and working your way to the bottom. Keeping the material wet, you will be able to slowly peel it from the wall and recover a clean wall.

If your wall was not well prepared or installed properly as outlined above, you may not achieve one piece removal.

Commercial Grade	g/m ²	Effect	Type	Printing	Washability	Recommended Application	Fire Certification*
Spray & Up Fibrous 167	167	Fibrous	Uncoated nonwoven	UV / LX	Washable	Light to medium traffic	B-s1-d0

* Certification Euroclass EN 13501-1:2007

We love seeing our products in action! Make sure to tag us on Instagram [@bigkidco](#) or use [#bigkidco](#) for a chance to be featured on our feed.

