



DIRECT RESPONSE MODULE REPLACEMENT

RV Kits

The Direct Response Module is located on the LH side (motor side) of the lead rail.

NOTE: The Freestyle awning will not operate electrically when the module is disconnected.

To Remove:

1. Extend the awning to access the inside of the lead rail.
2. Disconnect power to the awning.
3. Remove the two screws holding the module. Pull the module from the lead rail.

NOTE: The mounting brackets are held in place by tension from the screws. When the screws are removed, the brackets will sit loosely in the lead rail. Use care save the brackets.

4. Detach the quick release connectors.
5. Set the module aside.

To Install:

1. Connect the wires. Make sure to match wire color and size when making connections.
2. Position the brackets.
3. Tuck the wires and connectors behind the module and attach the module with the two screws removed previously.

