

Step 1:

On the back of the toolbox remove the 2 screws that hold the handle in place.

Step 2:

Using ONLY 7/32 or 5mm drill bit, widen the original holes you removed.

Step 3:

Use ONLY an M6-1.0 threaded bolt and preferred wrench/socket to create threads in the holes created.

Step 4:

Screw in the Quick Release Pins