



PARTS LIST				
No.	00764 100 QTY.	00764 150 QTY.	DESCRIPTION	
1	2	1	UPRT 00 470/292000	UPRIGHT ASSEMBLY
2	2	2	ROPE 00008 0G0	ROPE CLEAT
3	4	0	HDWE 06222	1/4" x 4" Lg. MACHINE SCREW
4	0	2	HDWE 06223	1/4" x 5 1/2" Lg. MACHINE SCREW
5	4	2	HDWE 03004 0E0	HEX NUT- 1/4-20

**Required Tools:**  
 Phillips Screwdriver

1. With PORTER sticker facing toward you, insert one screw through standard and cleat, toward cleat. Thread nut onto screw and lock nut into cleat on the left side of the standard (as shown).
2. Screw in cleat until tight.
3. Secure cleat with second screw and nut.
4. Repeat steps 1-3 for second standard.
5. Insert standards into ground sleeves (see Product Specification G-770 and INST00018036 for ground sleeve installation). Turn cleat side out for badminton courts or in for pickleball courts.
6. Install net as required.

**⚠ WARNING:** This product can expose you to Titanium Dioxide, which is known to the State of California to cause cancer. For more information go to [www.p65warnings.ca.gov](http://www.p65warnings.ca.gov).