



## Scout Campers Storage Cubby Net Installation

[Installation video available on our YouTube channel](#)

### Tools Needed:

- Phillips screwdriver

### Instructions:

1. Take each net and set them next to the corresponding cubby for your Scout model (follow the chart below)
2. Use a provided screw to attach the J-hook to the inside of the front wood on the bottom two corners of each cubby (no pilot hole should be needed but you may need to apply a good amount of force to get the screw to bite). Align all J-hooks to face away from the cubby opening.
3. Again, using the provided screws, attach the final two J-hooks on the inside of either side of the opening about  $\frac{2}{3}$  up from the bottom of the cubby. For the shorter cubbies, attach the J-hooks at the top of the cubby instead.
4. Attach the nets with the pocket opening facing up.

*\* In order of left to right, top to bottom when there are two cubbies lined up over each other. The first net 'A' will always be the Kitchenette opening.*

Kenai	Olympic	Yoho
A	A	A
A	D	B
A	D	C
C	B	B
B	B	D
C	C	E
	C	E
		F

We're a small business that takes every customer's concerns or constructive criticism to heart. Please share any experience, good or bad, with our company or products so that we can grow and be better!