

dapol 00/H0 TRACKSIDE MODEL C010: PLATFORM CANOPY

Made in the UK using recycled plastic



Not suitable for children under 14 years old

Please Note - The tools used to produce this model were made over 50 years ago. Over the period, changes have been made and it may be that reference numbers moulded into the plastic parts do not match the numbers used in these instructions. Therefore we advise you to FOLLOW the exploded diagram and instructions.

ASSEMBLY INSTRUCTIONS: It is recommended that the instructions and exploded view are studied, the various individual parts identified and that assembly is practised before cementing together. Some parts may best be painted and left to dry before attempting assembly.

WARRANTY:

Parts can get bent during transit or by prolonged storage. However misshapen parts can be straightened by placing them in hot water to soften the plastic and then carefully manipulating them back into shape by finger pressure. Please be careful that the water does not cause harm to skin or fingers. In the event of parts being broken or missing, then you **MUST** return to the place of purchase (the seller). The seller will replace your kit and return the original kit to Dapol under their agreed contractual terms. Do **NOT** return to Dapol.

Finally please note that Dapol does not keep individual parts for any kit.



CEMENT



ASSEMBLED SECTION

1

1: Cement bearers (2 -13) to side bar (1) and leave to dry.
2: Cement side bar (14) to bearers.

2

3: Repeat for opposite side using parts (15 -26) and (27).

3

4: Apply clear plastic film and cement roof finials (28 & 29) into place.

4

5: Cement main roof bearers (31 - 35) using the appropriate slots into the vertical roof bearers (30 & 36).

5

6: Cement completed roof (stage 2) to completed roof support (stage 3).

7: Cement both ends (37 & 38) into place to hold the complete assembly together.

6

8: Cement roof sides (39 & 40) to completed canopy (stage 4).
9: Cement the four post tops (41 - 44) over the corresponding studs on the underside of the roof.
10: Cement the four pillars (45 - 48) into the exposed holes of the post tops.