

# dapol 00/H0 TRACKSIDE MODEL C014: BOOKING HALL

Made in the UK using recycled plastic



Not suitable for children under 14 years old

**Please Note** - The tools used to produce this model were made over 50 years ago. Over the period, changes have been made and it may be that reference numbers moulded into the plastic parts do not match the numbers used in these instructions. Therefore we advise you to FOLLOW the exploded diagram and instructions.

**WARRANTY:** Parts can get bent during transit or by prolonged storage. However misshapen parts can be straightened by placing them in hot water to soften the plastic and then carefully manipulating them back into shape by finger pressure. Please be careful that the water does not cause harm to skin or fingers.

In the event of parts being broken or missing, then you **MUST** return to the place of purchase (the seller). The seller will replace your kit and return the original kit to Dapol under their agreed contractual terms. Do **NOT** return to Dapol.

Finally please note that Dapol does not keep individual parts for any kit.

**ASSEMBLY INSTRUCTIONS:** It is recommended that the instructions and exploded view are studied and that the assembly is practiced before cementing together. Certain parts may need to be trimmed and may best be painted before cementing.

**STAGE #1:** Identify both main walls (1 & 11) and note that they have inner and outer sides. Cement all windows (2 - 21) into position as shown, noting that the window sills face to the outside. Cement doors 15 and 19 in a closed position as shown. Doors 6 and 7 can be cemented in either an open or closed position. Finally cement half-door (16) into position as shown or this part can even be omitted. Then cement window (23) and door (25) into position on the two side walls (22 & 24)

**STAGE #2:** Cement main wall (1) to side wall (22 and main wall (11) to side wall (24) and allow to dry. Cement both wall sections together as shown in diagram <2>.

Cement external roof supports (26 - 29) into position of the front wall and then cement side fence (30) into position by the side door using the locating holes in the wall.

**STAGE #3:** Cement both chimneys together (31 - 36) and allow to dry. Cement drainpipe (37) into position to the right side of the main entrance using the locating holes in the wall.

**STAGE #4:** Cement main canopy (38) into position over the roof supports (26 - 29). Cement roof (39) into position as shown. Cement both chimneys into position on the roof and finally cement rear drainpipe (40) into position.

