

# M2 3rd Battery Install Instructions

## What's Included

Core SWX Gold Mount Plate w/ Pre-Wired Genuine LEMO Power Connector  
Apex Cinema Gear M2 3rd Battery Mounting Plate  
4x M3 Screws

## Tools Needed

Phillips #2 Screwdriver  
2mm Allen Key

It is not required that you remove the lower electronics from your Steadicam post, but it makes the install easier and is shown here for clarity.

### Step 1

Place all of your tools and parts on a clean and flat work surface.



### Step 2

Locate the 5 phillips screws on the bottom of your electronics.



### Step 3

Unscrew the 5 phillips screws and remove the cover plate. Place the 5 phillips screws to the side.



### Step 4

Place the M2 3rd Battery Mounting Plate on the electronics and attach using the 5 phillips screws you removed in step 3.



### Step 5

Attach the Gold Mount Plate to the 3rd Battery Mounting Plate with the provided M3 screws.



### Step 6

Re-attach the lower electronics to your post if needed and plug the 3-pin Lemo into either of the 12/24v ports on your sled.

