



## ***Installation Instructions for the Dodge Ram Exhaust System***

### **Tools Needed:**

- 15mm Socket with Ratchet or Air Ratchet
- Pry Bar
- WD-40 or Penetrating Oil

1. Begin by Spraying all of the rubber hangers rear of the muffler, as well as both Inlet and Outlet necks on the muffler.
2. Loosen the 15mm nuts on the front of the muffler clamp. Then Remove the factory muffler, leaving the rubber hangers on the truck in place.
3. Place the supplied hanger in the rubber. You will push it into place from the front so that the clamp closer to the drive shaft us the higher of the two clamps. (See Figure 1)
4. Slide the retro-fit muffler from B2 Fabrication into place using the rear hanger for alignment.
5. Place the factory tailpipes back into the factory rubber hangers and slide the tailpipes back into the muffler. Snug up 3" inlet clamp.

**Do not use slits in inlet/outlet for alignment! They are for clamp compression only!  
Do not tighten up yet.**

6. Align the tip in the bumper bezel and snug the tailpipe clamp.
7. Repeat the steps for the passenger side.
8. After checking alignment of the tailpipe tips, begin tightening clamps from the front to the back.

***That's it! You're done.  
Enjoy your new Exhaust!***

