

HAYMAN Original In-Floor Safe

INSTALLATION INSTRUCTIONS:

Pre-Installation Notes:

Remove the safe door before installation and store it out of the way. Only reinstall the door after the cement is set.

FS Doors Only: If your door did *not* ship in a different box: Remove the magnetic hinge covers over the hinge blocks. With the door open and vertical, grip the door handle with your right hand and the dead bolt on the hinge side with your left. Lift the door straight up and out.

S Doors: To Remove an S Door, simply unlock the door and lift up. The S Door is designed to be a non-hinged, lift-out door.

FS4000 only— Remove all contents from the safe. Place the wood brace into the safe about halfway down, centered from left to right, bridging across the corrugated sides. The brace should wedge between the walls snugly. This prevents the concrete from bowing the sides in.

While still in its plastic wrapping, place the dust cover (rectangular piece of steel with finger hole) on the body. Use duct tape around the corners so that the tape wraps down the side of the safe about ½ inches and completely covers the top edge. This will prevent cement from seeping in during installation.

Installing Safe in an existing concrete slab:

1. Make a hole in your slab about 3 inches larger than your safe on each side. To do this, add 6 inches to the width and depth dimension listed for the safe.
2. Dig out under the floor as illustrated to about 3 inches below position of safe. The more reinforced concrete that can be placed around safe, the greater the security.
3. Partially fill hole with concrete mixture, place the safe in the hole and push the safe down until the top is level with the finished floor.
4. Finish adding the new concrete around the safe. Make sure the top of the safe is kept level with finished floor.

Note: If safe is placed where water might run into it, raise safe slightly above floor level and taper concrete up to dust cover level.

FS4000 Only: Remove the wooden spacer which bridges across the corrugated walls, if present.

FS4000 Only: To install false floor, orient the steel false floor plates so that the short sides are resting on the bottom-center of the safe, and the long sides are resting on the molded ledge at either end of the body. Place carpet on top.

FS4000 & FS2300 Only To install file divider: The small plastic piece serves as the file divider – place it vertically so that it fits between the corrugated walls. You can move it side to side to adjust your needs.

FS Doors Only: To install door: Hold the door in your right hand by the handle and your left hand by the dead bolt on the hinge side of the door. Position the door over the hinge blocks on the door frame so that it is just past 90 degrees to the floor and lower the door into the hinge blocks. A slight push may be needed to seat the hinge pin into the hinge blocks. A light spray lubricant can be applied to the hinge pin after the door is installed. Position the two magnetic hinge covers over the hinge blocks.