

Installation shall be made entirely at your own risk. DevSport is **not** responsible for any and all damages caused by the improper installation of any product.

Note: This is a general outline for installation. Actual application may vary slightly.



- Open your door and roll down the window halfway.
- The Window Vents are side specific. Matte finish being the outside and gloss finish the inside.
- The Vents are designed to slide into the windows weather stripping channel.
- Loosely snug the Window Vents into the top of the window channel. Slowly roll up the window.
- The window will sit along the inside bottom of the Vent.
- With the window sitting along the bottom of the Window Vent, adjust the Window Vent as needed to fit and contour correctly along the window weather strip channel to fit snug.