Thermo Drain GUIDE FOR SELECTING PROPER MODEL LENGTH



Restricted Height

When you are restricted on height, we recommend the following to determine the maximum length ThermoDrain[™] to be installed.

Measure the length of the vertical stack where you wish to install the ThermoDrain . Subtract 2 1/2" from this total length. The result is the maximum length ThermoDrain you can install.

ThermoDrain comes in all lengths - We will manufacture any custom length at no extra charge.

Note: The 2 1/2 inches clearence is requiered to properly assemble the ThermoDrain onto the stack. You will requiere 1 1/4" at the top and 1 1/4" at the bottom.

Example: For 35 inch drain stack lenght 35 inches - 2.5 inches for the couplings = 32.5 inches total maximum length ThermoDrain to be installed.

