



Installation Instructions

For part #127056 Dyna/Street Bob LP6 Bracket for Memphis Shades Road Warrior Fairing

Kit Contains:

- 1- Main Bracket 127056-1
- 2- Stiffener Support Plate 127056 with 3/8 hole and 127056-3 with 5/16 hole.
- 1- 3/8 x 1 3/4 x 24 Grade 8 bolt & Nylock Nut Fine Thread
- 1- 5/16 x 1 3/4 x 24 Grade 8 bolt & Nylock Nut Fine Thread
- 1- 3/8 Grade 8 Washers 1- 5/16 Grade 8 Washers

Thanks for purchasing our Dyna/ Street Bob Lower Clamp Center Hole Mount for an LP6 Light. This bracket is very simple to install. IT does require a clean surface and a significant torque on the main bolt in order to insure proper install.

1. The main bracket attaches to your lower clamp 3/8" hole. See Image 1#. It's important to have the lower clamp. As per image below, this hole will secure the entire bracket and stiffener system.

Image#1



2. Reference the image below and use the matching stiffener plate for the bolt used. We have supplied two versions of the bracket: one with a 5/16 inch bolt and one with a 3/8 inch bolt.

Image#2



3. Locate the hole at the center of your lower clamp. Determine if your bike has a 3/8 hole or a 5/16 hole. Use the largest shoulder bolt that will fit. The bracket goes on top first, then choose the matching top plate or stiffener. Followed by a washer and nylock nut. Ensure that both the LP6 bracket and stiffener plate are straight and aligned with the lower clamp.

Part# 127056-1



#127056 Stiffener Plate with 3/8 Hole
#127056-3 Stiffener Plate with 5/16 Hole

Hardware kit:

- 1 - 3/8 x 1 3/4 x 24 Grade 8 Socket Head
- 1 - 5/16 x 1 3/4 x 24 Grade 8 Socket Head
- 1 - 5/16 Washer Grade 8
- 1 - 3/8 Washer Grade 8

4. Once the main bracket is tight and on bike, You can install the LP6 per instructions on your kit.

5. Wiring Instructions come with each wire kit.

6. The Road Warrior Fairing installs after light kit.

Cali Raised Moto	Phone: 714-534-6700
Part #: 127056	Rev #
Dyna/Street Bob LP6 Mount For Road Warrior Fairing	
File: Installation_ Instructions 127056 Install	