

INSTALLATION GUIDE

Sprinter Roof Rails

1. Remove the caps on the roof.



2. Clean all the dust around the holes with solvent.



3. Apply silicone or butyl tape around the hardware before dropping the roof rails on the roof for installation.



4. Install the washer and tighten the self locking nuts included in the package on the inside of the van.

