—— Instruction Manual ——

BA125/185



Instruction For Applying Vinyl Lettering On Ball Carts

NOTE: LETTERING TO BE APPLIED TO THE OUTSIDE OF EITHER BALL CART END

- Inspect all contents prior to installation. Report any missing parts to dealer immediately.
- Read all instructions before proceeding.
- 1) Prepare a solution of water and a very small amount of dish soap or other mild detergent.
- 2) Make sure the surface that lettering is to be applied to is clean.
- 3) Apply the water/soap solution liberally to the clean surface.
- 4) Carefully peel the stiff, clear backing sheet from the lettering, making sure that the letters stay affixed to the front of the contact sheet.
- 5) Carefully locate the remaining sheet containing the letters with the sticky side down on the outside of either ball cart end so that the letters are straight and centered as desired. The water/soap solution will allow some movement of the lettering.
- 6) With an edge of a credit card or similar object, squeegee the bubbles and water/soap solution from under the lettering making sure the entire image does not slip or slide.
- 7) After all bubbles are removed with the squeegee device and after insuring that the image is straight, allow to dry for approximately 1 hour.
- 8) Again using the credit card or similar object, make sure all letters are affixed, then remove the front paper from the lettering sheet and remove excess water/soap solution with a dry cloth.
- Using the edge of the credit card or similar object make sure all bubbles are removed and that all letters are still affixed.