

— Instruction and Safe Use Manual —

SCNOTIP

Portable Soccer Goal No-Tip Transport/Ballast Retrofit Kit



Customer Service
(800) 247-7668

PARTS LIST

| Item | Qty | Description | Item | Qty | Description |
|------|-----|-------------------|------|-----|--|
| A | 4 | Ballast Drum | D | 4 | Ballast Drum Plug (pre-installed) |
| B | 4 | Net Retention Bar | E | 16 | 1/4" X 3/4" Self Drilling/Threading Hex Screws |
| C | 8 | 3 3/4" Washer | F | 1 | 3/8" Hex Magnetic Screw Drive Socket |

- ◆ Inspect all contents prior to installation. Report any missing parts to dealer immediately.
- ◆ Read all instructions before proceeding.

NOTE:

Only compatible with Bison soccer goals with 1.66" diameter rear spreader bars.

1. Assemble the rest of the soccer goals according to instructions provided with the goal.
2. Detach the 1.66" diameter rear spreader bar from the T-Connectors previously mounted to the 1.66" side backstays. See Figures 1 and 2.
3. Loosen the 5/16" U-Bolts that attach the previously installed T-Connector to the backstay so that they move freely up and down on the angled section of the side backstays. See Figures 1 and 2.
4. Fill each *Ballast Drum* (A) completely with sand making sure that the sand is compacted. Each *Ballast Drum* (A) should hold 60-70 pounds of sand. Adding a small amount of water will help compact the sand. Once full, re-install the *Ballast Drum Plug* (D) and tighten securely to ensure that sand cannot escape.
5. Slide the *Ballast Drums* (A), *Net Retention Bars* (B) and *3 3/4" Washers* (C) onto each end of the 1.66" rear spreader bar as shown. See Figures 1 and 2.
6. Reinsert each end of the rear spreader bar into the receiver tubes on the T-Connectors attached to the side backstays. The T-Connectors will need to move up the backstay to make this attachment. Re-attach the rear spreader bar to the T-Connectors with hardware provided.
7. Position the *Net Retention Bars* (B), the *3 3/4" Washers* (C) and the *Ballast Drums* (A) approximately 4 feet from the side backstays. Using four #14 X 3/4" *Self Drilling/Threading Hex Screws* (E) per *Net Retention Bar* (B), attach the *Net Retention Bar* (B) to the rear spreader bar. See Figure 2.
8. Slide the T-Connectors up or down the angle of the side backstays until the bottom of the *Ballast Drums* (A) and the lower section of the side backstays are resting firmly on the ground when the goal is in the upright and playing position. Tighten the 5/16" U-Bolts on the T-Connectors.

9. Rear portion of the net close to the *Ballast Drums* (A) can be attached to the *Net Retention Bar* (B) with cable ties to avoid net entanglement when moving goals.
10. To move No-Tip portable goal, have two people lift the front of the goal enough for the goal to rest only on the *Ballast Drums* (A) allowing easy rolling on the surface of the field. See Figure 3.

