



Harper's Passenger Floor Board Kit

This kit includes the following: 1 pr floor boards; 2 square stock brackets; 4 SS spacers; 2 12X60 bolts; 2 12X70 bolts; 4 nuts and this page of instructions.

Instructions for Installing Passenger Pegs on a Moto Guzzi



Remove foot peg from aluminum bracket.

Remove both bolts holding aluminum bracket to frame. **Use caution as this separates two frame sections and will take some realignment.**



Replace bolts with new bolts and spacers (supplied with our kit) thru the bracket, as shown. Use the spacers between the bracket and the aluminum in the counter-bunk holes.

Install footboards into the square bracket. Use one spacer and bolt supplied. Repeat for opposite side.

Harper Accessories warrants the *Harper Floorboard Kit* against defects in materials and workmanship for a period of 90 days from date of purchase. Must have invoice for return.

Improper installation or any alteration of the product renders all warranties null and void. Warranty is limited to the replacement or repair of the floorboard kit only, which is at the discretion of Harper Accessories.

Thank you for purchasing another Harper Accessory Product.