

# VersaTrax – RailTrax Install Instructions

## Parts Included:

- (2) RailTrax Rails
- (4) RailTrax Bolts
- (1) TP50 (Torx Plus 50) 3/8" Drive
- (4) Single Stud L-Series Fittings

**Step 1:** Remove the (4) OEM bed bolts utilizing a T55 (Torx 55) drive *(see photo 1)*.

**Step 2:** Position each *RailTrax Rail* between the bed bolt holes. Ensure the lettering is facing outwards to allow the paracord anchor point to be properly utilized *(see photo 2)*.

**Step 3:** Install the (4) *RailTrax Bolts* through each slot on the *RailTrax Rails* and secure directly to the frame of the vehicle utilizing the TP50 (Torx Plus 50) drive included.

**Step 4:** Torque each bolt to 50 ft/lb.

**Step 5:** Connect/disconnect any L-series tie down fittings as required to secure your cargo.

*Note: Parts/positions being referenced are highlighted in blue in the photos.*

