

# Perfect Installation

1. Create trench around perimeter of plant rootball
2. Slip Greenwell together ensuring the zip joint is fully slid 'home'. The join It will click when slid all the way home.
3. Nestle the Greenwell into place keeping it level
4. Fill with soil inside and out to ground level. Top of root ball should be level with surrounding terrain
5. Finish with a layer of mulch and fertiliser as required
6. When the earth settles and hardens the Greenwell will be locked firmly into place.
7. Remove (spade required) and reuse after 2-3 years or when plant is well established.



Greenwell is sitting above ground and will not hold any water



Greenwell regular size set about 50% into the earth

# Good Install Examples



Large Greenwell in Surrey BC Canada set about 30% into sidewalk

TIP: Set deeper in sandy soil - water will penetrate soil quickly. In clay base soil set quite shallow as shown above. Water will 'well' up to the brim and penetrate more slowly.

If water escapes from the join then check that the zip join is fully engaged and snapped closed at the rim.



Regular Greenwell in Newcastle Australia set deeply on sloping ground



Regular Greenwell in CA set about 50% into loose soil.