DROP IT MODERN

THIS WALLPAPER REQUIRES PROFESSIONAL INSTALLATION DO NOT CUT OR INSTALL BEFORE READING THESE INSTRUCTIONS

HAVE A QUESTION?

We are here to support you and get you back on track. Mon-Fri 6A-2P PST: 971-645-9168 or info@dropitmodern.com

IMPORTANT

Inspect your order within five (5) days of receiving it. If drop it MODERN is not made aware of any issues within this 5 day window, any potential replacement order would have to be paid by customer. Verify the pattern and quantity before opening the first roll. Check the wallpaper for any issues. Find something that's not right? Stop immediately (do not install defective material) and contact us so we can correct your order. If no defect is evident before installation, the material should be inspected after three (3) panels are installed. Product must be installed by a professional installer experienced with double cutting. drop It MODERN is not responsible for errors in paper due to incorrect trimming or hanging practices. If any defect is evident at this time (or at any point in the installation) no additional material should be hung until drop it MODERN is notified. No claims will be allowed for more than 3 panels on the wall. No labor claims will be allowed at any time. Please note, we will require the defective material to be sent back to us for inspection.

ABOUT OUR WALLPAPERS

Straight match in the pattern orientation. We offer several different paper types that vary in widths. Confirm which type you are using before starting. Standard panel length is 10'L. Customized orders vary in length. If you order more than one panel, they will be bundled and shipped together.

UNTRIMMED PANELS AND DOUBLE CUTTING

Wallpaper panels are untrimmed and require double cutting. ALL ORDERS arrive with 1" WIDTH OVERLAP on left and right sides of panel (2" total per panel) to protect wallpaper during shipping and installation and allow for perfect butted seams via double cutting. 0.5" of this border is unprinted and should be removed before hanging. 0.5" of this border is printed and provides the overlap on the wall before double cutting. Once this protective border is trimmed: 30"W untrimmed papers provides 26"W nominal use / 54"W untrimmed paper provides 52"W nominal use. CUSTOMIZED ORDERS arrive with 2" HEIGHT OVERAGE on bottom of panels to aid in positioning during installation.

BUILDING & MATERIAL CONDITIONS

The building must be weather-tight with HVAC settings (including pressure, temperature and relative humidity) the same as those of an occupied building (55 degrees F) for two (2) days prior to, throughout installation and two (2) days after installation. The walls must be structurally sound including elimination of sources of moisture accumulation into the wall or wall cavity. The wallpaper must be in a clean and dry condition and must be stored at normal occupied building temperature and humidity for at least two (2) days prior to installation. Walls must be clean, dry, and professionally primmed prior to installation.