

OVERVIEW

- Pro Bond® Adhesive Primer must be applied to wall prior to installation
- Suggested for residential and apartment use
- Repositionable *Note: one time use only
- Opaque
- Tear strength
- Apply to clean dry surface
- Walls must be flat and smooth, not for use on textured walls, will compromise adhesive and paper could bubble or peel away
- Allow 30 days for newly painted walls to outgas before installation
- Use a warm damp cloth to clean surfaces prior to installation
- Straight match



- For best results, keep unused product wrapped and stored as recommended above – exposure to wide fluctuations in temperature or humidity may adversely affect performance

HAVE A QUESTION?

We are here to support you and get you back on track.
Mon-Fri 6A-2P PST: 971-645-9168 or info@dropitmodern.com

IMPORTANT

Inspect your order within five (5) days of receiving it. If drop it MODERN is not made aware of any issues within this 5 day window, any potential replacement order would have to be paid by the customer. Verify the pattern and quantity before opening the first roll. Check the wallpaper for any issues. Find something that's not right? Stop immediately (do not install defective material) and contact us so we can correct your order. If no defect is evident before installation, the material should be inspected after three (3) panels are installed. Products must be installed by a professional installer experienced with double cutting. drop It MODERN is not responsible for errors in paper due to incorrect trimming or hanging practices. If any defect is evident at this time (or at any point in the installation) no additional material should be hung until drop it MODERN is notified. No claims will be allowed for more than 3 panels on the wall. No labor claims will be allowed at any time. Please note, we will require the defective material to be sent back to us for inspection.

ABOUT OUR WALLPAPERS

All of our papers have a straight match. Standard panel length is 10'L. Customized orders vary in length. If you order more than one panel, they will be bundled and shipped together.

UNTRIMMED PANELS AND DOUBLE CUTTING

Wallpaper panels are untrimmed and require double cutting. ALL ORDERS arrive with 1" WIDTH OVERLAP on left and right sides of panel (2" total per panel) to protect wallpaper during shipping and installation and allow for perfect butted seams via double cutting. 0.5" of this border is unprinted (white border) and should be removed before hanging. 0.5" of this border is printed and provides the overlap on the wall before double cutting. Once this protective border is trimmed: 30"W untrimmed papers provides 26"W nominal use / 54"W untrimmed paper provides 52"W nominal use. CUSTOMIZED ORDERS arrive with 2" HEIGHT OVERAGE on bottom of panels to aid in positioning during installation.

BUILDING & MATERIAL CONDITIONS

The building must be weather-tight with HVAC settings (including pressure, temperature and relative humidity) the same as those of an occupied building (55 degrees F) for two (2) days prior to, throughout installation and two (2) days after installation. The walls must be structurally sound including elimination of sources of moisture accumulation into the wall or wall cavity. The wallpaper must be in a clean and dry condition and must be stored at normal occupied building temperature and humidity for at least two (2) days prior to installation. Walls must be clean, dry, and professionally primed prior to installation.

INSTALLATION / WALL PREPARATION:

Wallcovering installation has many variables. These instructions are intended as a guide for many common scenarios. For unique applications please contact our customer support. The wall surface should be clean, thoroughly off-gassed from priming or painting (app. 30 days from painting.) Peel & Stick paper will adhere to most common paints in most surfaces including eggshell, satin, semi-gloss, gloss and matte. Washable paints and No VOC paints prohibits full adhesion. To counter this limitation the wall can be thoroughly wiped down with isopropyl alcohol with a rag. Wall surface should be tested for adhesion with a 24" x 24" swatch to assess adhesion. In the case of poor adhesion due to no VOC paint, use primer as directed or wallpaper glue can be applied to the perimeter of each panel.

CARE

We encourage preventative maintenance by using a protective topcoat during installation to prevent stains. As needed, clean wallpaper with warm water and a non-abrasive, microfiber cloth using a blotting motion, do not rub or use solvent type cleaning solutions. Dry wall covering with a lint free cloth or towel. Grease and oil stains are unlikely to come out. Do not use any abrasive tools that may scratch the paper. drop it MODERN is not liable for damages brought to wallpaper due to improper cleaning techniques.