

## VINTAGE VIBE:

### Vibanet Preamp - FX Loop Plate Installation Template for Clavinet C & D6

1. Print pdf at 1:1 scale.
2. Measure 2" length to the right to ensure the template is printed to the correct scale.
3. Cut out template along outer lines.
4. Position template against back of piano:
  - Ensure that the upper edge of the template is flush to the top of the piano.
  - Ensure that the original output and power jack holes and labeling will be adequately covered by the new plate.
5. Use Gaffer or Painter's tape to **securely** adhere template to piano.
6. With an awl, mark the center of each of the eight mounting holes.
7. With an awl, mark the center of each of the four points indicated within the dashed box.
8. With an exacto knife or box cutter, cut out the inner dashed box from the template:
  - Cut deep enough as to not only remove the paper but also score the tolex and wood beneath.
9. Using a 5/16" bit, drill out the four points marked during step #7.
10. Use a jigsaw to cut out the inside of the template.
11. Remove remaining portion of template.
12. Using a 1/16" bit, drill out the eight mounting holes marked during step #6.
13. Install the new jack plate onto the piano using the included mounting screws.

