



**FF-453**

## **BONGO / FREDA FRONT WHEEL ARCH TRIMS**

### **Fitting Instructions**



We recommend to bond the wheel arch trims to the vehicle and use a clamp to hold them in place.

Then you may fix with the rivets provided from the inner plastic part of the wheel arch.