



VW T4 LIMITED EDITION BONNET BRA FITTING INSTRUCTIONS

Before You Begin Fitting Your Product, Please Ensure Your Bonnet Is Clean And Dry. This limited edition bonnet bra instruction is designed to for this type of bonnet bra only. These instructions are not to be used with any other bonnet bra types

***** PLEASE ENSURE YOU HAVE THE CORRECT BONNET BRA FOR YOUR VEHICLE *****

1. First of all, open and raise your bonnet halfway. (It is easier if you have someone to assist you).
2. Attach the corners closest to the windscreen first.

PLEASE DO NOT PULL TIGHT ON THE CORNER OF THESE BONNET BRAS

3. Slowly and carefully stretch the bonnet bra into position, towards the headlamp corners.
4. At this point, the cover should be fitted loosely.
5. Fully open the bonnet and use the bonnet stick.
6. Prepare the hooks supplied in the kit and fit them to the bonnet bra. These hooks can be positioned to your preference. Ensure you have positioned the hooks evenly and have covered all areas.

Please refer to images below for example how the hooks should fit.





7. Now that all the hooks are ready on the bonnet bra, attached the supplied rope from one bottom corner and zig-zag the rope between each hook.
8. Once you have finished looping, tie the rope and gently close your bonnet.
9. Make sure you are satisfied with the fit and that the rope is tied securely and out of the way.
10. Well Done! You have successfully fitted your bonnet bra.



If You Still Have Problems/Difficulties Fitting Your Bonnet Bra, Please Contact Us:

Telephone: 01782 280 888 | **E-Mail:** info@van-x.co.uk | **Website:** www.van-x.co.uk |
WhatsApp: 01782 454 897