



FF-453 MB453

BONGO / FREDA REAR WHEEL ARCH TRIMS

Fitting Instructions



We recommend to bond the wheel arch trims to the vehicle and use a clamp to hold them in place.

Then you may fix with the rivets provided from the inner plastic part of the wheel arch.